

H.C.B-C1184 HINO CRANKSHAFT FRONT OIL SEAL INSTALLER (J08C)



* This tool is designed for preventing oil seal from damage while installing. Save time and labor. * Application: HINO 10.5?15?17 TON * Oil seal genuine no.: BZ4820E

Rating: Not Rated Yet

Price:

Sales price:

Discount:

[Ask a question about this product](#)

Manufacturer: [HCB Specialty Tools](#)

Description

STEP 1 Remove the old oil seal from the crankshaft.

STEP 2 Apply the H.C.B-C1184 HINO Crankshaft Front Oil Seal Installer (J08C) to the crankshaft.

STEP 3 Install the new oil seal into the crankshaft.

STEP 4 Remove the H.C.B-C1184 HINO Crankshaft Front Oil Seal Installer (J08C) from the crankshaft.

STEP 5 Check the oil seal installation.

STEP 6 Complete the oil seal installation.

